


AudioVisual Room Guide

Source Controls



Help Menu

Pressing this button will open the HelpMenu Controls. Pressing the Emergency button will send a request to a technician to troubleshoot an issue right away.
(M-Th: 8am-10pm; Fri: 8am-5pm)

Source Controls - Pressing any of these buttons will send an image to the projector or LCD TV.

PC - Sends PC image to the projector or LCD TV.

Laptop - Sends Laptop image to the projector or LCD TV. Connect using either VGA or HDMI cable on lectern.

DocCam - Sends Document Camera image to the projector or LCD TV. Ensure Doc. Cam is powered on.

Video Mute - Blanks projector image, press a different input to restore video.

Room Controls - Pressing any of the buttons at the bottom will bring up the following room control options .

System Off- Turns off projector and raises projector screen. A cool-down before turning projector back on will take place.

Volume Controls - Adjust input audio level to speakers in room.


Light Controls - Adjust lighting level in room (where applicable).

Room Controls - Flips to another page for more advanced control of projector, projector screen, LCD TV, microphones, cameras and advanced routing.

AudioVisual Room Guide

Room Controls Page

Device Controls



Advanced Routing

Pressing this flips to another page, giving you advanced control of which inputs route to different outputs.

Device Controls - Pressing any of these will allow you control of each individual device.

- Microphones** - Allows individual control of the microphones over the loud-speaker.
- Camera Control** - Allows access to pan/tilt/zoom as well as presets for the lecture-capture camera.
- Sesnor Control** - Allows access to customize or enable/disable room control sensors, such as the Occupancy Sensor.

Display Controls - These buttons allow manual control of the room display devices.

- Projector**- Turns on/off the projector. A cool-down before turning projector back on will take place.
- Proj Screen** - Brings up/down the projector screen.
- DMPS** - Turns on/off the main video switcher of the room.
- Speaker Amp** - Turns on/off the speaker amplifier of the room.